



fingers®

Quick Start Guide

Duo-Recharge Wireless Combo
Wireless Deskset

I. Important - Warnings and Safety Instructions

1. Do not place the deskset (keyboard + mouse) near the heat sources such as radiators, fire, stoves, light candles and other apparatus that produces heat.
2. Keep it dry. Do not allow the deskset (keyboard + mouse) to get wet or expose to moisture/rain, else it increases probability of fire or shock occurrences.
3. Use only those accessories supplied by FINGERS.
4. Refer all servicing to qualified personnel. Servicing is required when the deskset (keyboard + mouse) has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

Choking Hazard

This device may contain small parts which may be a choking hazard to children under 3. Keep small parts away from children.

II. In the box

- 1 x FINGERS Duo-Recharge Wireless Combo
(Wireless Keyboard + Wireless Mouse)
- 1 x Nano USB Receiver
- 1 x USB-A to USB-C Charging Cable
- 1 x Quick Usage Guide
- 1 x Brand Note

III. Getting Started



Laptop




1. Turn on your PC/Laptop
2. Then plug the Nano USB Receiver into a USB port of your PC/Laptop.
And, you're good to go.

IV. Charging

- Plug the Mouse/Keyboard into a USB port using Type-C charging cable provided.
- While charging, the LED turns ON.
Once fully charged, the LED turns off.
- Allow up to 2 hours to completely charge the mouse


Please note: Use only USB to Type-C cable for charging.

V. Mouse Features



1. Left and Right Buttons
2. Scroll Wheel
3. DPI button (to change cursor speed -
800 / 1200 / 1600 CPI)
4. Nano USB Receiver storage
5. On/Off switch
6. Type-C charging port

VI. Keyboard Features



1. FN + F1 >> Play Media Player

2. Fn + F2 > Decrease Volume

3. Fn + F3 > Increase Volume

4. Fn + F4 > Mute Volume

5. Fn + F5 > Next Track

6. Fn + F6 > Previous Track

7. Fn + F7 > Play/Pause

8. Fn + F8 > Stop

9. Fn + F9 > Web/Home

10. Fn + F10 > Mail

11. Fn + F11 > My Computer

12. Fn + F12 > Favourite

13. Calculator²

14. Notes²

15. Type-C charging port

16. On/Off Switch

17. Nano USB Receiver storage

VII. Care and Maintenance

1. Use soft, damp cloth to clean the surface.
2. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
3. Do not allow any liquid to enter into any of the openings.

VIII. Product Specifications

Technology	Optical 2.4 GHz Wireless Technology
System Requirements	<i>OS Support:</i> Microsoft® Windows® macOS Linux Chrome OS <i>Interface:</i> USB Port (2.4 GHz USB nano)
Effective Range	Up to 10 m
Colour	Keyboard: Jet Black Mouse: Matte Black + Steel Grey

Keyboard

No. of keys	106 keys
Power Source	3.7 V 500 mAh Rechargeable Battery
Charging Time	Up to 2 hours
Battery Life¹	Up to 25 days
Switch Life	10 million life cycles
Dimensions	456 (L) x 141 (W) x 27 (H) mm
Weight	468 g

Mouse

Type	Wireless Optical
Charging Time	Up to 2 hours
Battery Life¹	Up to 25 hours
Button	4 buttons with scroll wheel Left, Right, Middle, DPI switch
Power Source	3.7V 500 mAh Rechargeable battery
Resolution	800/1200/1600 DPI (Changeable)
Switch Life	5 million life cycles
Dimension	35 (H) x 64 (W) x 109 (L) mm
Weight	60 g



fingers.co.in | Ver.: 2.0.0

¹Tested under ideal conditions. Battery life may vary depending on usage.

²The dedicated keys may only work well on Windows® OS.

• Images shown may vary from actual product. • Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in