

Quick Start Guide

Mini MOT (My-Own-TV)
Portable Speaker



I. Important - Warnings and Safety

1. Do not place the speaker near heat sources such as fire, radiators, stoves and other apparatus that produce heat.
2. Use only accessories supplied by FINGERS.
3. Unplug the speaker/Mic once it is fully charged, when unused for long periods of time or during lightning/thunderstorms.
4. It is recommended to refer all servicing to qualified personnel. Servicing is required when the speaker has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

II. In the box

- 1 x FINGERS Mini MOT (My-Own-TV)
- 1 x USB Charging Cable
- 1 x Quick Start Guide
- 1 x Brand Note


III. Mobile Stand

The speaker has a mobile stand function which can be rotated 360 degrees and adjusted freely from any angle. Additionally, comes with RGB lights at the bottom.



IV. Connections

1. Multi-switch
2. LED Indicator
3. USB Port
4. Charging Port



Connection	Function
Multi-Switch	When moved to R - Speaker and RGB lights are on
	When moved to On - Speaker is on while RGB lights is off
	When moved to Off - Speaker & RGB lights are switched off
LED Indicator	When charging, the red light is on.
	While the light goes off when fully charged.
USB interface	Insert a USB drive and play.
Type-C port	For Charging

V. Charging

- A red light indicates that it is in DC charging mode.
- Once it is completely charged, the red LED glow disappears.

VI. Modes

You can enjoy your music in the following ways

i. Bluetooth ii. USB

i. Bluetooth Mode

- When the device is switched on, it automatically goes to BT mode.
- Make sure that Bluetooth is enabled on your device.
- Find the device list and select "FINGERS Mini MOT (My-Own-TV)".
A sound prompt of "Connected" is heard and it is ready to play.



Manage Calls

Can receive/end calls on the speaker if your mobile device is connected to the speaker.

2 BT devices using Multi-Point Technology

- Turn off the BT function of first connected device, and search "FINGERS Mini MOT (My-Own-TV)" in 2nd Device.
- Repeat the above steps (3 & 4) to pair another device
- Turn Off the FINGERS Mini MOT (My-Own-TV) Portable speaker, once 2nd device is connected successfully.
- Switch on the BT function on 1st device and FINGERS Mini MOT (My-Own-TV) portable speaker.
- As the speaker remembers previously connected devices - When switched on, it attempts to reconnect both previously paired devices.
- Now the Speaker is ready to use, with both the paired devices.

ii. USB

- Insert the USB device (Pen Drive) in the provided port.
- You can then play your favourite tracks directly from the USB.

VII. Care and Maintenance

1. Switch off the speaker before cleaning it.
2. Use soft cloth to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.

VIII. Product Specifications

Parameters	FINGERS Mini MOT (My-Own-TV)
Wireless Protocol	Bluetooth v5.3
Peak Output Power	5 W
Power Rating	DC 5 V / 1 A
Driver unit	4Ω 5W
Effective Range	Wireless range up to 10 m
Battery	800 mAh / 3.7 V
Charging Time	Up to 2 hours
Playback Time*	Up to 6 hours
Playback Options	Bluetooth® USB
Microphone	Built-in
Dimensions	121 mm x 73 mm x 190 mm (L x W x H)
Weight	290 g
Colours	Black

fingers.co.in | Ver. 1.0.0

Tested under ideal conditions and in BT playback mode. Playback time may vary depending on usage, playback mode and volume levels.

• Images shown may vary from actual product. • Specifications, features and appearance are subject to change without notice.
• All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in