



fingers[®]

Quick Start Guide

Go-Hi-3
True Wireless Earbuds

I. Important - Warnings and Safety Instructions

1. While placing the earbuds in your ears, please keep the volume down and then gradually adjust the volume to an appropriate, comfortable level.
2. Prolonged use at high volumes might damage your hearing.
3. Focus on your safety and that of others. We recommend not listening to music while riding or driving, or at any time where the inability to hear surrounding sounds may present a danger to yourself or others.
4. If you experience a warm sensation or loss of audio, please remove and disconnect immediately.
5. Do not place the product near heat sources such as fire, radiators, stoves, light candles and other apparatus that produces heat.
6. To avoid accidental ingestion, keep the earbuds away from small children and pets. The earbuds contain a lithium battery, and may be hazardous if swallowed. If ingested, seek immediate medical attention. When not in use, place the earbuds in the charging case with the lid closed, thereby keeping them out of reach from small children and pets.
7. Use only those accessories supplied by FINGERS.
8. Unplug the Charging Case once it is fully charged , when unused for long periods or during lightning/ thunderstorms.
9. It is recommended to refer all servicing to qualified personnel. Servicing is required when the device has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.


CAUTION: Do not use earbuds while on swim and shower.

II. In the box


- 1 x FINGERS Go-Hi-3 (Charging Case + TWS Pods)
- 1 x USB Charging Cable
- 2 x Extra Ear-gels
- 1 x Quick Start Guide
- 1 x Brand Note

III. On-board Controls

1) Earbuds



2) Charging Case



Soft Touch control functions

What to do	Function 1	Function 2
Single Tap (L/R earbud)	Play/Pause	Receive incoming Call
Long Touch for 2 secs (L/R earbud)	Voice Assistant	Reject Incoming Call
Long Touch for 4 secs (L/R earbud)	Power On-Off	

While Grooving Music

Single Tap (L/R earbud)	Play/Pause	
Double Tap (L/R earbuds)	R earbud - Next Track L earbud - Previous Track	
Triple Tap (L/R earbuds)	R earbud - Volume Up L earbud - Volume Down	

During Calls

Single Tap (L/R earbud)	End Call	
-------------------------	----------	--

IV. How to wear

- Insert the earbud into the ear.
- Tilt and rotate the earbud until it fits comfortably and microphone is pointing at the bottom of ear, towards mouth.



V. Charging

With up to 5 hours of playback time in the earbuds and 2.5 times recharges in the charging case, FINGERS Go-Hi-3 provides up to 17.5 hours of playtime.

V.1) Earbuds

- The earbuds charge while they are in the Charging Case.
- Place R and L earbuds in the Charging case. A blue light appears on Charging Case, indicating that it is in charging mode.
- The LED disappear when it is fully charged, and Charging Case will be switched off automatically to stop charging.
- It takes approximately 1 hour to charge the earbuds fully.

V.2) Charging Case


- Plug the Charging Case into a USB Power Supply using USB Type-C charging cable provided.
- While charging, the LED turns red and blinking. Once it is completely charged, it turns to stable red.
- Allow up to 1 hour to completely charge the Charging Case whereas around 1 hour 20 minutes for Charging Case with earbuds.

Note: Please use only Type-C cable for charging.

VI. Bluetooth® Pairing

VI. 1) TWS Mode

- Take out any of the earbuds from the Charging Case and switch it on.
- Make sure that Bluetooth® is enabled on your device. Find the device list and select “FINGERS Go-Hi-3”. Once the Bluetooth® connection is successful, a sound beep “connected” is heard and it is ready to play.
- Another earbud will get connected with first one automatically as soon as it is taken out from charging case and switched on.



VI. 2) Single Earbud

- Take out any one of the earbuds from the Charging Case and switch it on.
- Make sure that Bluetooth® is enabled on your device. Find the device list and select “FINGERS Go-Hi-3”. Once the Bluetooth® connection is successful, a sound beep “connected” is heard and it is ready to play.

Note: Both buds can be connected separately with 2 different mobile phones and can be used as single ear-bud.

VII. Care and Maintenance

1. Switch off the earbuds before cleaning it.
2. Use a soft, damp cloth to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.

VIII. Product Specifications

Parameters	Go-Hi-3
Wireless Protocol	Bluetooth v5.3 + BR + EDR + BLE
BT Profiles Supported	AA2DP, AVRCP, HFP
Input Power Rating	DC 5.0 V 1 A Max.
Driver unit	Φ13 mm
Effective	
Frequency Range	2.402 ~ 2.480 GHz
Effective Range	Up to 10 m
Battery Capacity	Charging Case: 180 mAh Each Earbud: 25mAh
Battery Type	Li-Polymer
Charging Time	Charging Case: Up to 1 hour 20 mins Each Earbud: Up to 1 hour
Playback Time*	Up to 5 hours
TalkTime*	Up to 4 hours
Standby Time	Up to 80 hours
Dimensions	Charging Case: 61 x 21 x 45 mm (L x W x H) Earbuds: 22.1 x 21.2 x 27 mm (L x W x H)
Weight	Charging Case: 29 g Earbuds each: 4 g for each



¹Tested under ideal conditions and varies depending on usage and volume levels.

²Tested under limited conditions. Do not immerse it in liquid.

• Images shown may vary from actual product. • Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in

Safety Notes: • When in use, please adjust the volume to appropriate level. • Excessive use at high volumes may damage your hearing. • For your traffic safety, we recommend to not to listen music while riding or driving.