

fingers®



Quick Start Guide

ANC-HopBeats
ACTIVE NOISE CANCELLATION
TWS EARBUDS

I. Important - Warnings and Safety Instructions

1. While placing the earbuds in your ears, please keep the volume down and then gradually adjust the volume to an appropriate, comfortable level.
2. Prolonged use at high volumes might damage your hearing.
3. Focus on your safety and that of others. We recommend not listening to music while riding or driving, or at any time where the inability to hear surrounding sounds may present a danger to yourself or others.
4. If you experience a warm sensation or loss of audio, please remove and disconnect immediately.
5. Do not place the product near heat sources such as fire, radiators, stoves, light candles and other apparatus that produces heat.
6. To avoid accidental ingestion, keep the earbuds away from small children and pets. The earbuds contain a lithium battery, and may be hazardous if swallowed. If ingested, seek immediate medical attention. When not in use, place the earbuds in the charging case with the lid closed, thereby keeping them out of reach from small children and pets.
7. Use only those accessories supplied by FINGERS.
8. Unplug the Charging Case once it is fully charged , when unused for long periods or during lightning/ thunderstorms.
9. It is recommended to refer all servicing to qualified personnel. Servicing is required when the device has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

CAUTION: Do not use earbuds while on swim and shower.

II. In the box

- 1 x FINGERS ANC-HopBeats (Charging Case + TWS Pods)
- 1 x USB Charging Cable
- 2 x Extra Ear-gels
- 1 x Quick Start Guide
- 1 x Brand Note

III. On-board Controls

1) Earbuds



2) Charging Case



Soft Touch control functions

What to do	Function 1	Function 2
Single Tap (L/R earbud)	Play/Pause	Receive incoming Call
Double Tap (L/R earbuds)	R earbud - Next Track L earbud - Previous Track	Reject / Hang Up incoming Call
Triple Tap (L/R earbuds)	R earbud - Volume Up L earbud - Volume Down	
Long Press on Right Earbud for 2 secs	Switch to ANC ON, Transparent Mode and ANC OFF	
Long Press on Left Earbud for 2 secs till it beeps	Voice Assistant	
Four Taps (Right Earbud)	Navigate Sound Effects of Hi-Fi, Rock and Bass	

IV. How to wear

- Insert the earbud into the ear.
- Tilt and rotate the earbud until it fits comfortably and microphone is pointing at the bottom of ear, towards mouth.



V. Charging

With up to 5.5 hours of playback time in the earbuds and 3 times recharges in the charging case, FINGERS ANC-HopBeats provides up to 22 hours of playtime.

V.1) Earbuds

- The earbuds charge while they are in the Charging Case and the lid must be closed.
- Place R and L earbuds in the Charging case. A green light appears on the Charging Case, indicating that it is in charging mode.
- The LED disappear when it is fully charged. It takes approximately 1 hour 05 mins to charge the earbuds fully.

V.2) Charging Case


- Plug the Charging Case into a USB Power Supply using USB Type-C charging cable provided.
- While charging, the LED turns green and flashes. Once it is completely charged, it turns to stable Green and then it will turn off.
- Allow up to 1 hour to completely charge the Charging Case and approximately 1 hour 15 mins to charge Charging Case with earbuds.

Note: Please use only Type-C cable for charging.

VI. Bluetooth Pairing

VI. 1) TWS Mode

- Take out any of the earbuds from the Charging Case and Switch it on.
- The earbud flashes in red & blue frequently, signifying that it is ready to pair a device.
- As it flashes red & blue, make sure that Bluetooth is enabled on your device. Find the device list and select "FINGERS ANC-HopBeats". Once the Bluetooth connection is successful, a sound beep "connected" is heard and it is ready to play.
- Another earbud will get connected with first one automatically as soon as it is taken out from charging case and switched on.
- Please note that the earbuds will automatically get connected to previously connected device when the lid of Charging case is opened (Snap & Pair Technology).



VI. 2) Single Earbud

- Take out any one of the earbuds from the Charging Case and the earbud flashes on.
- The earbud flashes in red & blue frequently, signifying that it is ready to pair a device.
- As it flashes red/blue continuously, make sure that Bluetooth is enabled on your device. Find the device list and select "FINGERS ANC-HopBeats". Once the Bluetooth connection is successful, a sound beep "connected" is heard and it is ready to play.

Note: Both buds can be connected separately with 2 different mobile phones and can be used as single ear-bud.

VII. Care and Maintenance

1. Switch off the earbuds before cleaning it.
2. Use a soft, damp cloth to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.

VIII. Product Specifications

Parameters	ANC-HopBeats
Wireless Protocol	Bluetooth v5.4 + BR + EDR + BLE
BT Profiles Supported	A2DP.1.2/ AVCTP.1.4.1/ AVDTP.1.3.4/ AVRCP.1.6.2/ GAVDP.1.3.1/ HFP.1.8/ HID.1.0.14/ IOPT.4.0.1/ RFCOMM.1.2.2/ SPP.1.2.2
Input Power Rating	DC 5.0 V 1 A Max.
Driver unit	Φ10 mm, 32 Ω
Effective	
Frequency Range	2.402 ~ 2.480 GHz
Effective Range	Up to 10 m
Battery Capacity	Charging Case: 300 mAh Each Earbud: 40mAh
Battery Type	Li-Polymer
Charging Time	Charging Case: Up to 1 hour 15 mins Each Earbud: Up to 1 hour 05 mins
Playback Time*	Up to 5.5 hours
TalkTime*	Up to 4 hours
Standby Time	Up to 80 hours
ANC Range	25 dB
Dimensions	Charging Case: 59 x 30 x 41 mm (L x W x H) Earbuds: 36 x 15 x 21 mm (L x W x H)
Weight	Charging Case: 31 g Earbuds each: 4 g each



*Tested under ideal condition and varies depending on usage and volume levels.

• Images shown may vary from actual product. • Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners.

• Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in

fingers.co.in | Ver.: 1.0.0