

fingers[®]



Quick Start Guide

CherryGrip
Wireless Mouse

I. Important - Warnings & Safety Instructions

1. Do not place the mouse near the heat sources such as radiators, fire, stoves, light candles and other apparatus that produce heat.
2. Focus on your safety and that of others. We recommend keeping it dry and not allow the mouse to get wet or exposed to moisture/rain, which may present the possibility of fire or shock to yourself or others
3. Use only those accessories supplied by FINGERS.
4. It is recommended to refer all servicing to qualified personnel. Servicing is required when the keyboard has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

CAUTION

This device contains small parts which are hazardous to children. Keep it away from children of age 3 and under.


II. Care and Maintenance

1. Switch off the mouse before cleaning it.
2. Use a soft, damp cloth to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.

III. In the box

- 1 x FINGERS CherryGrip
- 1 x USB Receiver
- 1 x Type-C Charging Cable
- 1 x Quick Start Guide
- 1 x Brand Note

IV. On-board Controls



V. Charging

- Plug the mouse into USB port using the provided Type-C Charging Cable.
- Allow up to 2 hours for the mouse to fully charge.

Please note: Use only Type-C cable for charging. When its in charging mode LED turns green and when its full charged LED disappears.

VI. Setting up

i. USB Receiver Mode



Step a:

Open the Mouse case and take out the USB receiver

Step b:


Plug the USB receiver into your Laptop/PC.




Step c:

Slide the MFB Button on upper side to switch to USB receiver Mode. You're ready to use!

ii. Bluetooth Mode



- **Step a:** Slide the MFB Button on the bottom side of the mouse, Then press and hold the right-click button and scroll wheel simultaneously till the mouse enter pairing mode. The LED will blink blue to indicate pairing.



- **Step b :** On your tablet, laptop, smartphone or other Bluetooth-enabled device, go to the Bluetooth® settings, enable Bluetooth®, find device list and select “CherryGrip”.
Once successfully connected, you’re all set!

Please note: You can connect two devices at a time - one with USB receiver and another with Bluetooth® mode.

VII. Product Specifications

Parameters	CherryGrip
Technology	Optical Technology (2.4 GHz Wireless) + Bluetooth® v5.2
Button	5 Buttons with Scroll Wheel: Left Right Middle DPI button MFB Button - On-Off/Mode Change
Power Source	Rechargeable battery: 3.7 V, 500 mAh Charging Voltage: 5 V, 500 mA
Wireless Effective Range	Up to 10 m
Charging Type	Type-C for Charging
Charging Time	Up to 2 hours
Battery Backup Time	Up to 25 days*
Resolution	800 - 1200 - 1600 DPI (Changeable)
Interface	USB / Bluetooth®
System Requirements	Microsoft® Windows® macOS 10.10 Linux ChromeOS iPadOS Android 11 and above
Dimensions	104 (L) x 63 (W) x 36 (H) mm
Weight	72 g



fingers.co.in | Ver.1.0.0

*Tested under ideal conditions and varies depending on usage.

• Images shown may vary from actual product.

• Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in