

Quick Start Guide

Musilicious3
Portable Speaker



fingers

I. Important - Warnings and Safety

1. Use only accessories supplied by FINGERS.
2. Unplug the speaker once it is fully charged, when unused for long periods of time or during lightning/thunderstorms.
3. It is recommended to refer all servicing to qualified personnel.
Servicing is required when the speaker has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.
4. Do not place the speaker near heat sources such as fire, radiators, stoves and other apparatus that produce heat.


II. Care and Maintenance

1. Switch off the speaker before cleaning it.
2. Use a soft cloth to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.

III. In the box


- 1 x FINGERS Musilicious3 Speaker
- 1 x Type-C Charging Cable
- 1 x Quick Start Guide

IV. Connections



Connections	Function
1. Type-C Port	To charge the speaker
2. LED indicator	- Red LED glows while charging
	- Turns off when fully charged
	- Blue LED blinks when in BT pairing mode
3. USB Port	Insert a USB drive and then play.

V. On-board Controls



Button	Function
1. Power On-Off / MFB	• Long press to turn the speaker On/Off • BT & USB Mode: Single press to play/pause music • FM Mode: Single press to mute/unmute; double press to auto-search channels • Calling Mode: Single press to answer/end calls; double press to last call; Long press reject incoming calls
2. Volume Up	• Long press to increase volume • BT & USB Mode: Single press to skip to the next track • FM Mode: Single press to switch to the next saved channel
3. Volume Down	• Long press to decrease volume • BT & USB Mode: Single press to go to the previous track • FM Mode: Single press to switch to the previous saved channel
4. Mode	Press to change speaker mode (BT / FM / USB)

VI. Modes

You can enjoy your music in the following ways:

i.BT ii.FM Radio iii.USB

i. BT

-When the device is switched on, it automatically goes to BT mode.

-If any source is connected (USB, MicroSD or AUX), press "M" button till BT Mode is heard.

-Make sure that BT is enabled on your device.

Find the device list and select

"FINGERS Musilicious3". A sound prompt of "Connected" is heard and it is ready to play.



Connecting 2 BT Devices (Multi-Point Technology)

1. Turn ON the speaker and connect it to the first device via BT.
2. Once connected, turn OFF BT on the first device.
3. Now, search and connect the speaker (FINGERS Musilicious3) from the second device.
4. After the second device is connected, turn ON BT on the first device again.
5. The speaker will automatically reconnect to the first device.
6. Both devices are now connected to the speaker and ready for use.

ii. FM Radio

- Press on the "M" button till the voice prompt of the word "FM Mode" is heard.

- Double press "⏻" to scan the stations automatically.

You can again double press the same button to stop the scan.

- Once the FM radio is tuned, you can short press "+" and "-" to select the desired FM Channel.

- Short press "⏻" to mute the FM.

iii. USB

- Insert the USB device (Pen Drive) in the provided port.

- You can then play your favourite tracks directly from the USB.

VII. Product Specifications

Parameters	Musilicious3
Wireless Protocol	BT v6.0
Peak Output Power	5 W
Power Rating	DC 5V / 1A
Power Source	Built-in Rechargeable Battery
Driver unit	2" 4Ω 5W
Effective Range	Wireless range up to 10 m
Battery	1200 mAh
Charging Time	Up to 3.2 hours
Playback Time	Up to 4 hours ²
Playback Options	BT FM Radio ¹ USB
Microphone	Built-in
Dimensions	121 x 85 x 39 mm (L x W x H)
Weight	214 g

Stay connected with us

f @fingers.co.in **X** @FingersIndia **o** @FingersIndia

Customer Service

- Support email: customer.care@fingers.co.in
 - +91 74004 88454: Mon - Fri (9.30 am to 6.30 pm)
- For further information, please visit www.fingers.co.in



¹For better FM reception, connect USB cable which works as an antenna.

²Tested under ideal conditions and in BT playback mode. Playback time may vary depending on usage, playback mode and volume levels.

• Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners and protected under IPR. • Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in

