



# Quick Start Guide

Dial-ANC

Wireless Active Noise Cancelling Headphones

## **I. Important - Warnings & Safety Instructions**

1. While placing the headphone in your ears, please keep the volume down and then gradually adjust the volume to an appropriate, comfortable level.
2. Prolonged use at high volumes might damage your hearing.
3. Focus on your safety and of others. We recommend not to listen music while riding or driving, or at any time when the inability to hear surrounding sounds may present a danger to yourself or others.
4. If you experience a warm sensation or loss of audio, do remove and disconnect immediately.
5. Do not place the headphone near heat sources such as fire, radiators, stoves, light candles and other apparatus that produces heat.
6. Use only those accessories supplied by FINGERS.
7. Unplug the headphone once it is fully charged, when unused for long periods of time or during lightning/thunderstorms.
8. It is recommended to refer all servicing to qualified personnel. Servicing is required when the device has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

## **II. In the box**

- 1 x FINGERS Dial-ANC
- 1 x USB Type-C Charging Cable
- 1 x Quick Start Guide

### III. On-board Controls



| Button | Function                 | What to do                                        |
|--------|--------------------------|---------------------------------------------------|
| On/Off | Multi-Function (MFB)     |                                                   |
|        | On-Off                   | Long Press                                        |
|        | Play/Pause               | Short Press                                       |
|        | Next Track               | Double Press                                      |
|        | Previous Track           | Triple Press                                      |
|        | During Calls             |                                                   |
|        | Receive Call             | Short Press                                       |
|        | End Call                 | Again, Short Press                                |
|        | Reject incoming call     | Long Press                                        |
|        |                          |                                                   |
| ANC    | ANC Mode On/Off          | Single Press                                      |
|        | Gaming Mode / Music Mode | Double Press                                      |
| Dial   | Volume Increase          | Rotate the dial clockwise (left to right)         |
|        | Volume Decrease          | Rotate the dial counter-clockwise (right to left) |

### IV. Charging

- A red light indicates that the device is in charging mode.
- Once fully charged, the LED light will turn off.

## V. Enjoy music in following ways

### i. BT

-Long Press the “MFB button” to switch on the headphone till the LED indicator starts flashing in red and blue alternately, signifying that it is ready to pair the device.



- As it flashes red and blue alternately, make sure that BT is enabled on your device. Find the device list and select “FINGERS Dial-ANC”.
- To connect another device, turn off the first connected device and pair the second device. After pairing, turn the first device back on. Both devices will remain connected.

### ii. AUX

Insert the AUX external audio cable and the audio system will automatically play back with priority and prompt tone.

## VI. Care and Maintenance

1. Switch off the device before cleaning it.
2. Use soft, damp cloth to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.

## VII. Product Specifications

| Parameters                | Dial-ANC                         |
|---------------------------|----------------------------------|
| Wireless Protocol         | BT v6.0                          |
| Driver unit               | Φ 40 mm                          |
| Effective Frequency Range | 2.402 GHz ~ 2.480 GHz            |
| Effective Range           | Up to 10 meters                  |
| ANC Range                 | > 20 - 500Hz                     |
| ANC noise reduction       | 23 ± 3 dB                        |
| Battery                   | 500 mAh                          |
| Charging Time             | Around 2.5 hours                 |
| Playback Time*            | Up to 33 hours                   |
| Talktime*                 | Up to 35 hours (Noise reduction) |
| Standby Time              | Up to 200 hours                  |
| Playback Options          | BT   AUX                         |
| Dimensions                | 200 (L) x 83 (W) x 195 (H) mm    |
| Weight                    | 228 g                            |



fingers.co.in

Ver.:1.0.0

\*Tested under ideal conditions and in BT playback mode. Playback time may vary depending on usage, playback mode and volume levels.

• Images shown may vary from actual product. • Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on [www.fingers.co.in](http://www.fingers.co.in) • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website [www.fingers.co.in](http://www.fingers.co.in)