



fingers®

Quick Start Guide

AeroClicks-D11
Wireless Deskset

I. Important – Warnings and Safety

Safety Instructions

1. Do not place the keyboard & mouse near heat sources such as fire, radiators, stoves and other apparatus that produce heat.
2. Keep it dry. Do not allow the keyboard/mouse to get wet or expose to moisture/rain, else it increases the occurrences of fire or shock.
3. Use only those accessories supplied by FINGERS.
4. Refer all servicing to qualified personnel. Servicing is required when the deskset (keyboard + mouse) has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

Choking Hazard


This device may contain small parts which may be a choking hazard to children under 3. Keep small parts away from children.

II. In the box

- 1 x FINGERS AeroClicks-D11 (Wireless Keyboard + Wireless Mouse)
- 1 x USB Nano Receiver
- 1 x Quick Start Guide

III. Getting Started

Keyboard/Mouse Connection




- Turn on your PC or laptop
- Insert the batteries into both the keyboard and the mouse.
- Plug the Nano USB receiver into an available USB port on your PC or laptop. And, you're good to go!

IV. A. Keyboard Features



FN + F1	Home
FN + F2	Mail
FN + F3	Search
FN + F4	Media Player
FN + F5	Play/Pause
FN + F6	Previous Track
FN + F7	Next Track
FN + F8	Decrease Volume
FN + F9	Increase Volume
FN + F10	Mute Volume
FN + F11	My computer
FN + F12	Calculator

B. Mouse Features



V. Product Specifications

Parameters	AeroClicks-D11
Technology	Optical 2.4 GHz Wireless Technology
System Requirements	OS Support: Microsoft® Windows® macOS Linux Chrome OS Interface: USB Port (2.4 GHz USB nano)
Effective Range	Up to 10 m

Keyboard

No. of keys	104 keys
Power Source	1 x AA Alkaline Battery
Dimensions	436 (L) x 132 (W) x 23 (H) mm
Weight	354 g

Mouse

Type	Wireless Optical
Button	4 Buttons with Scroll Wheel - Left Right Middle DPI 1 x On-Off Switch
Power Source	1 x AA Alkaline Battery
Resolution	800 / 1000 / 1400 DPI (Changeable)
Dimensions	108 (L) x 64 (W) x 35 (H) mm
Weight	58 g

VI. Care and Maintenance

1. Use a soft, damp cloth (water only) to clean the surface.
2. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
3. Do not allow any liquid to enter into any of the openings



Stay connected with us



Customer Service

- Support email: customer.care@fingers.co.in
- +91 74004 88454

For further information, please visit www.fingers.co.in

fingers.co.in | Ver.: 1.0.0

• Images shown may vary from actual product. • Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in