fingers

Quick Start Guide

AeroGlide WB6

Wireless Mouse

I. Important - Warnings & Safety Instructions

1. Do not place the mouse near the heat sources such as radiators, fire, stoves, light candles and other apparatus that produce heat.
2. Focus on your safety and that of others. We recommend keeping it dry and not allow the mouse to get wet or exposed to moisture/rain, which may present the possibility of fire or shock to yourself or others
3. Use only those accessories supplied by FINGERS.
4. It is recommended to refer all servicing to qualified personnel. Servicing is required when the keyboard has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.


CAUTION


This device contains small parts which are hazardous to children.
Keep it away from children of age 3 and under.

II. In the box

1 x FINGERS AeroGlide WB6
1 x USB Receiver
1 x AA Battery
1 x Quick Start Guide
1 x Brand Note

III. On-board Controls







IV. Modes

a. USB Wireless Mode:


You can use a Mouse by using a USB Receiver.





Step 1: Insert AA Battery on back side of the Mouse.
Step 2: Take out the USB receiver from the back side of the Mouse.
Step 3: Plug the USB Receiver into a USB port of your PC/Laptop.
Step 4: Switch on the Mouse by using the On-Off Switch. And, you're good to go!

b. BT Mode:



Step 1: Insert AA Battery on back side of the Mouse.
Step 2: Mouse will turn on automatic BT mode & pairing mode.
Step 3: On your BT-Enable device, open BT Settings ⟶ Enable BT ⟶ Check the available device list and select 'FINGERS AG' to pair.

Note:
If the mouse does not connect via BT, please follow the steps below:

1. Press and hold the Right Click button and the Middle Button (Scroll Wheel) together for 5-6 seconds to enter BT pairing mode.
2. Once the mouse enters pairing mode, the green LED inside the mouse will blink rapidly, indicating that it is ready to pair.
3. If the USB receiver is connected to the system, the mouse will not switch to BT mode. Please remove the USB receiver before attempting BT pairing.
4. If the mouse still does not enter pairing mode:
   - Remove the USB receiver (if connected).
   - Turn the mouse OFF.
   - Remove and reinsert the battery.
   - Turn the mouse ON.
   - Then, press and hold the Right Click button and the Middle Button (Scroll Wheel) together for 5-6 seconds until the green LED starts blinking rapidly.

V. Care and Maintenance

1. Switch off the mouse before cleaning it.
2. Use a soft, damp cloth to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.

VII. Product Specifications

Parameters	AeroGlide WB6
Technology	Optical Technology (2.4 GHz Wireless) + BT v5.2
Button	4 Buttons with Scroll Wheel
Power Source	1 x AA Size Alkaline Battery
Wireless Effective Range	Up to 10 m
Resolution	800 /1200/ 1600 DPI (Changeable)
Interface	USB (2.4 GHz USB nano Receiver)
System Requirements	OS Support: Microsoft® Windows® | macOS | Linux | ChromeOS
Dimensions	110 (L) x 73.82 (W) x 33.7 (H) mm
Weight	71 g

EPR Details

fingers.co.in I Ver.1.0.0

*Tested under ideal conditions and varies depending on usage.

• Images shown may vary from actual product.

• Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in