Quick Start Guide

RGB-NoviTrend

Wireless Mouse

I. Important - Warnings & Safety Instructions

1. Do not place the product near heat sources such as fire, radiators, stoves, light candles and other apparatus that produces heat.
2. Focus on your safety and of others. We recommend to keep it dry and do not allow the mouse to get wet or expose to moisture/rains, which may present possibility of fire or shock to yourself or others.
3. Use only those accessories supplied by FINGERS.
4. It is recommended to refer all servicing to qualified personnel. Servicing is required when the device has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

CAUTION

This device contain small parts which is hazardous to children. Keep it away from children of age 3 and under.

II. In the box

1 x FINGERS RGB-NoviTrend

1 x Type-C Charging Cable

1 x USB Receiver

1 x Quick Start Guide

1 x Brand Note

III. On-board Controls



1 - Left and Right Buttons
2 - Scroll Wheel
3 - Power On-Off and RGB LED switch
4 - Bluetooth® Pairing Switch
5 - Type-C Charging Port

IV. RGB Lights switch operation modes



Position1: Mouse ON; RGB Light OFF
Position2: Mouse ON; RGB Light ON
Position3: Power OFF

V. Charging

- Plug the Mouse into a USB port using Type-C charging cable provided.
- While charging, the LED turns green. Once completely charged, it turns to solid green.
- Allow up to 1.5 hours to completely charge the mouse
  Please note: Use only USB to Type-C cable for charging.

V. Modes

You can use Mouse in the following various ways
i. Bluetooth®
ii. USB Receiver

i. Bluetooth®

Pairing with Tablets, Smartphones, Laptop, PC and other Bluetooth®-enabled devices

- Step 1: When the Mouse is powered on, the Red light on back side will illuminate for 2 seconds and then turn off to save power. Here in this case, please note that the Mouse is still on.
- Step 2: Press and hold Bluetooth® Pairing switch for 2 seconds. The mouse will go to the Pairing mode.
- Step 3: Go to your "Settings" screen on your tablet, laptop, smartphone or other Bluetooth-enabled devices and go to the Bluetooth® Setting menu. Activate its Bluetooth® function, find the device list and select *FINGERS RGB-NoviTrend*.
- Step 4: Once successfully connected, red indicator on the back side will be switched on and you’re good to go.

ii. USB Receiver



- Step 1: Switch on your Mouse.
- Step 2: Open the Mouse case and take out the USB receiver.
- Step 3: Plug the USB Receiver into a USB port of your PC/Laptop. And, you're good to go!

You can use the Mouse connected with 2 different devices with both modes at the same time.



On pressing - Bluetooth® mode is activated and is connected with device where Bluetooth® connection is established.
While pressing again - USB mode is activated is connected with other device where USB receiver is plugged in.

VII. Care and Maintenance

1. Switch off the mouse before cleaning it.
2. Use soft, damp cloth to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.

VIII. Product Specifications

Parameters	**RGB- NoviTrend**
Technology	Wireless Optical Technology + Bluetooth® with illuminating LED lights
Button	5 Buttons with Scroll Wheel
Power Source	300 mAh battery - Lithium rechargeable
Wireless Effective Range	Up to 10 meters
Charging Type	Type-C for fast charging
Battery Backup Time	With RGB LED On: 1time charge/1week backup With RGB LED Off: 1 time charge/9 days backup
Resolution	1000 DPI
Interface	USB/Bluetooth®
Switch Life	5 million life cycles
System Requirements	> OS Support: Windows® I Mac I Linux I Chrome OS I Android 11 and above > Interface: USB Port
Dimensions	3.7 (H) x 5.5 (W) x 10.0 (L) cm
Weight	60 g
Colour	Piano Black

fingers.co.in I Ver.1.0.0

[1]Tested under ideal conditions. It may vary depending on usage levels.
[2]Tested under limited conditions. Do not immerse keyboard in liquid.

• Images shown may vary from actual product. • Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners.

• Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in